
Omaha Standard

OWNER'S MANUAL

Installation, Operating, Safety, and Maintenance Instructions with Parts Lists

519 DH HOIST



Omaha Standard, Inc.

Truck Bodies and Hoists

3501 South 11th Street • Council Bluffs, IA

51501-3633 U.S.A.

Phone (712) 328-7444 FAX (712) 328-8383

PART # 31-25900

NOVEMBER 2002

WESTERN PRODUCTS, P.O. BOX 245038, MILWAUKEE, WI 53224-9538

Lit. No. 64319, Rev. 08
December 14, 2005

UltraMount SYSTEM®

OWNER'S MANUAL
Straight Blades with Isolation Module Electrical System

WESTERN®

SNOWPLOWS

⚠ CAUTION
Read this manual before operating or servicing snowplow.

This document supersedes all editions with an earlier date.

A DIVISION OF DOUGLAS DYNAMICS, L.L.C


S/N EM003299 #17

ELKIN

HI - TECH

PARTS, INSTALLATION AND MAINTENANCE MANUAL

Model 2000 / 2100 / 2200 / 3000



Material Spreaders

Elkin Manufacturing, Inc.
2879 Oakland Avenue, Indiana, PA 15701
Phone: 724-349-6300 or 800-245-6899
Fax: 724-349-5987

WESTERN PRODUCTS, P.O. BOX 245038, MILWAUKEE, WI 53224-9538

Lit. No. 64295
August 26, 2004

WESTERN®

SYSTEM
UltraMount®

Straight Blade Service Parts for Hydraulic Assemblies with Isolation Module Electrical System

WESTERN Factory Original
DESIGNED-TESTED-APPROVED
PARTS & ACCESSORIES

A DIVISION OF DOUGLAS DYNAMICS, L.L.C.

WESTERN PRODUCTS, P.O. BOX 245038, MILWAUKEE, WI 53224-9538

Lit. No. 66899, Rev. 06
November 3, 2005

WESTERN®

SYSTEM UltraMount®

PRO PLUS®

Service Parts for PRO PLUS® Plows

WESTERN Factory Original
DESIGNED-TESTED-APPROVED
PARTS & ACCESSORIES

A DIVISION OF DOUGLAS DYNAMICS, L.L.C.